
N80 HILUX BATTERY BRACKET INSTALL


INSTALLATION IS VERY SIMPLE, THE BATTERY BRACKET SIMPLY BOLTS ONTOP OF THE EXISTING BATTERY HOLD-DOWN CLAMP NUTS. THIS MEANS THE BATTERY CLAMP DOESNT NEED TO BE LOOSENED OR REMOVED. THE N80 BATTERY BRACKET IS SECURED VIA THE ADDITIONAL M6 NYLOCK NUTS AND WASHERS.

TIGHTENING OF THE NUTS IS EASIEST WITH A DEEP 10MM SOCKET THROUGH THE TOP ACCESS CUTOUTS.




N80 HILUX BATTERY BRACKET INSTALL





N80 HILUX BATTERY BRACKET INSTALL


BLUE SEA SYSTEMS 5025
FUSE BLOCK




TRIPLE CIRCUIT BREAKER
MOUNTING POSITIONS

DESIGNS

N80 HILUX BATTERY BRACKET INSTALL





MIL-SPEC DESIGNS